




NO.	Code	English Name	Quantity
1	8440-471501	Switch push rob group	1
1-1	8086-462701	Wheel Pin	1
1-2	8121-462701	Slide Wheel	1
1-3	8043-471501	Switch push rod	1
2	8001-471502	Right rear left handle	1
3	8SJAB50-16B	Self –trapping screw	6
4	8005-471501	Strip	1
5	8440-467607	Pump Group	1
5-1	8187-471501	Pump fix board	1
5-2	8123-472201	Worm gear	1
5-3	8121-472201	Worm wheel	1
5-4	8304-472201	Piston Sleeve	1
5-5	8292-472201	Piston Support	1
5-6	8204-472201	Sealing Ring	1
5-7	8211-472201	Piston Sleeve	1
5-8	8336-472201	Pump body	1
5-9	8SNAB30-12B	Self –trapping screw	1
5-10	8061-471501	Oil tube	1
6	8SJAB40-25B	Self –trapping screw	1
7	8181-462701	Back plate	1
8	8440-467608	Oil Glid	1
8-1	8204-462201	O-Ring	1
8-2	8213-471501	Oil Adptor	1
9	8440-467609	Braking Rod Group	1
9-1	8SJAN50-12B	Machine screw	1
9-2	8202-462203	Braking washer	1
9-3	8324-462701	Spring Leaf	1
9-4	8043-462702	Divider Rod	1
9-5	8WF-05B	Washer	1
9-6	8342-462302	Braking Rob spring	1
9-7	8187-471502	Braking Rob Fix spring	1
9-8	8147-462701	Braking	1
10	8042-463103	Control switch	1
11	8CE-07B	E-circlip	1
12	8128-462201	Sprocket	1

13	8208-462201	Gland Bonnet	1
14	8342-462304	Spring	1
15	8440-467610	Shaft Group	1
15-1	8085-471501	Shaft	1
15-2	8342-462301	Braking spring	1
15-3	8063-462701	Shaft sleeve	1
15-4	8123-471502	Umbrella gear	1
15-5	BC-082207-ST	608Z rear bearing	1
15-6	8NG-08D	Self-trapping Screw	1
16	8440-467611	Tank Group	1

16-1	8213-462701	Output adaptor	1
16-2	8326-462701	sponge	1
16-3	8348-462701	Adaptor Choke Plug	1
16-4	8331-462701	Rubber Sleeve	1
16-5	8165-471501	Tank	1
17	8SJAB50-35B	Sef-tapping screw	1
18	8181-463101	Chain bar (16"oregon)	1
19	8344-463101	Saw chain (16"oregon)	1
20	8452-463101	Blade cover	1
21	8261-463101	Spanner	1
22	8207-463101	Tension nut	1
23	8207-481001	Tension screw	1
24	8440-471501	End cap group	1
24-1	8208-462305	End cap seal	1
24-2	8021-471501	End Cap	1
24-3	8208-471401	Brand label	1
24-4	8334-463101	Shaft Sleeve	1
24-5	8ND-08D	Flange nut	1
25	8185-463101	Nut Shield	1
26	8440-467613	Middle cover group	1
26-1	BC-102206-ST	6900Z bearing	1
26-2	8208-462204	output oil glib seal	1
26-3	8347-471501	Middle cover insert	1
26-4	8206-462202	Machine screw	1
26-5	8202-462205	seal shim	1

26-6	8023-471501	Middle cover	1
26-7	8SJAN40-12B	Machine screw	1
27	8SJAB40-14B	Self-tapping screw	1
28	8SJAB50-35B	Self-tapping screw	1
29	8SJAB50-16B	Self-tapping screw	1
30	8181-471501	Buffer Board	1
31	8413-462201	Connection wire	1
32	8044-471501	Switch Trigger	1
33	8440-462708	Oil cover Group	1
33-1	8335-463102	Value Group	1
33-2	8208-463101	Seal	1
33-3	8020-462701	Tank cover	1
33-4	8326-462302	Sponge	1
33-5	8371-462301	Air bag	1
33-6	8204-462301	Seal ring	1
34	8SJAN50-20B	Self-tapping screw	1
35	8146-471501	Variable-speed Box	1
36	8SJAN50-50B	Self-tapping screw	1
37	8207-472201	Nut	1
38	8123-471501	Small umbrella gear	1
39	8440-473501	Rotor Groupware	1
39-1	BC-123210-ST	6201Z front bearing	1
39-2	8402-471501	Rotor	1
393	BC-082207-ST	698z rear bearing	1
40	8440-473502	Housing Groupware	1
40-1	8182-471501	Wind screen	1
40-2	8SJAN50-60B	Self-tapping screw	1
40-3	8405-471501	Stator	1
40-4	8006-471501	Housing	1
40-5	8408-463101	Brush holder	1
41	8416-471501	Capacitor	1
42	8440-467612	Assistance handle Group	1
42-1	8003-471501	Left assistance handle	1
42-2	8003-471502	Right assistance handle	1
42-3	8SJAB40-14B	Self-tapping screw	1
43	8SJAB40-14B	Self-tapping screw	1
44	8440-467611	Rear left handle Group	1

44-1	8422-467601	Cable	1
44-2	8332-353201	Cable Sleeve	1
44-3	8001-471501	Rear left handle	1
44-4	8181-302201	Cable Holder	1
44-5	8SJAB40-14B	Self-tapping screw	1
45	8312-471501	Switch Knob	1
46	8042-462201	Switch	1
47	8407-463101	Brush cover	1
48	8406-463102	Brush	1
49	8342-471502	push rod spring	1
50	8SJAB30-8B	Self-tapping screw	1
51	8SJAB40-14B	Self-tapping screw	1